William Stallings Computer Organization and Architecture

Chapter 3

System Architecture

- Le persone che scoprono la potenza e la bellezza di idee di alto livello di astrazione spesso commettono l'errore di credere che le idee concrete a livelli inferiori di astrazione sono tutto sommato inutili e possono essere dimenticate.
- Al contrario, i migliori informatici sono sempre saldamente radicati nei concetti basilari che governano il funzionamento dei calcolatori, ed in verità **l'essenza dell'informatica è l'abilità di comprendere e governare molti livelli di astrazione contemporaneamente**.

- Donald Knuth, Keynote Address at the 8th Annual Conference on Innovation and Technology in Computer Science Education (ITiCSE-03)

From hardware to software

- Hardwired systems are inflexible
  - Changing function requires changing the wiring
  - e.g.: sum 2 numbers with k digits, sum k numbers
- But general purpose hardware can do different tasks, given correct control signals
- Supply a new set of control signals as needed under the control of a “program”

What is a program?

- A sequence of steps
- For each step, an arithmetic, logical, control or data movement operation is done
- For each operation, a different set of control signals is needed

Execution of the program

- For each operation a unique code is provided
  - e.g. ADD, MOVE
- A hardware circuit interprets the code and issues the control signals

- We have a computer!

The von Neumann computer



von Neumann/Turing architecture

- Binary representation for data and program
- Main memory storing data AND PROGRAMS
- Control unit interpreting instructions from memory and executing
- Normal control flow is sequential
- Specialized device (ALU) to operate on data
- Memory accessed by means of address
- Input and output equipment operated by control unit

Architecture & Organization 1

- Architecture expresses those attributes visible to the programmer (i.e.: functions, commands)
  - Instruction set, number of bits used for data representation, I/O mechanisms, addressing techniques.
  - e.g. Is there a multiply instruction?
- Organization is how features are **implemented**
  - Control signals, interfaces, memory technology.
  - e.g. Is there a hardware multiply unit or is it done by repeated addition?
- Architecture = Specification
- Organization = Implementation

Architecture & Organization 2

- All Intel x86 family share the same basic architecture
- The IBM System/370 family share the same basic architecture

- This gives code compatibility
  - At least backwards
- Organization differs between different versions

Structure & Function

- Structure is the way in which components relate to each other
- Function is the operation of individual components as part of the structure

- Structure = static relations among components
- Function = dynamic behaviour of each component

Function

- All computer functions are:
  - Data processing
  - Data storage
  - Data movement
  - Control

Structure - Top Level



Structure - The CPU



Structure - The Control Unit



Computer Components: Top Level View

- Central Processing Unit (CPU)
- Memory
- I/O
- System Interconnections (usually a “bus")



Components

- Central Processing Unit (CPU):
  - Control Unit
  - Arithmetic and Logic Unit
  - Internal Registers
- Input/output
  - Data and instructions need to get into the system and results out
- Main memory
  - Temporary storage of code and results is needed

CPU Components: Top Level View



CPU: Function of registers

- Program Counter
  - Address of the next instruction
- Instruction Register
  - Code of instruction to execute
- Accumulator
  - Temporary storage for ALU operations
- Memory Address Register
  - Memory address where to R/W
- Memory Buffer Register
  - Data read/written from/to memory



Instruction Cycle

- Two phases:
  - Fetch
  - Execute



Fetch Phase

- Program Counter (PC) holds address of next instruction to fetch
- Processor fetches instruction from memory location pointed to by PC
- Instruction loaded into Instruction Register (IR)
- Increment PC (but PC may be changed later...)

Execute Phase

- Processor decodes instruction and set-up circuits to perform required actions
- Actual execution of operation:
  - Processor-memory
    - data transfer between CPU and main memory
  - Processor-I/O
    - Data transfer between CPU and I/O module
  - Data processing
    - Some arithmetic or logical operation on data
  - Control
    - Alteration of sequence of operations
    - e.g. jump
  - Combination of above

A very simple processor

- INSTRUCTION: OP_CODE + ADDRESS

- OP_CODES:
  - 1 (address) -> Accumulator
  - 2 Accumulator -> address
  - 5 (address)+Accumulator -> Accumulator

Example of Program Execution



Instruction Cycle - State Diagram



Connecting

- All the units must be connected
- Different type of connection for different type of unit
  - Memory
  - Input/Output
  - CPU

Memory Connection

- Receives and sends data
- Receives addresses (of locations)
- Receives control signals
  - Read
  - Write
  - Timing

Input/Output Connection(1)

- Similar to memory from computer's viewpoint
- Data (during output operations)
  - Receive data from computer
  - Send data to peripheral
- Data (during input operations)
  - Receive data from peripheral
  - Send data to computer

Input/Output Connection(2)

- Receive control signals from computer
- Send control signals to peripherals
  - e.g. spin disk
- Receive addresses from computer
  - e.g. port number to identify peripheral
- Send interrupt signals (control)

CPU Connection

- Reads instruction and data
- Writes out data (after processing)
- Sends control signals to other units
- Receives (& acts on) interrupts

Buses

- There are a number of possible interconnection systems
- Single and multiple BUS structures are most common
- e.g. Control/Address/Data bus (PC)
- e.g. Unibus (DEC-PDP)

What is a Bus?

- A communication pathway connecting two or more devices
- Usually broadcast
- Often grouped
  - A number of channels in one bus
  - e.g. 32 bit data bus is 32 separate single bit channels
- Power lines may not be shown

Data Bus

- Carries data
  - Remember that there is no difference between “data” and “instruction” at this level
- Width is a key determinant of performance
  - 8, 16, 32, 64 bit

Address bus

- Identify the source or destination of data
- e.g. CPU needs to read an instruction (data) from a given location in memory
- Bus width determines maximum memory capacity of system
  - e.g. 8080 has 16 bit address bus giving 64k address space

Control Bus

- Control and timing information
  - Memory read/write signal
  - Interrupt request
  - Clock signals

Bus Interconnection Scheme



- Every device is attached to the bus:
  - its use needs to be coordinated

Big and Yellow?

- What do buses look like?
  - Parallel lines on circuit boards
  - Ribbon cables
  - Strip connectors on mother boards
    - e.g. PCI
  - Sets of wires

Single Bus Problems

- Lots of devices on one bus leads to:
  - Propagation delays
    - Long data paths mean that co-ordination of bus use can adversely affect performance
    - If aggregate data transfer approaches bus capacity
- Most systems use multiple buses to overcome these problems

Traditional (ISA) (with cache)



High Performance Bus



Bus Types

- Dedicated
  - Separate data & address lines
- Multiplexed
  - Shared lines
  - Address valid or data valid control line
  - Advantage - fewer lines
  - Disadvantages
    - More complex control
    - Ultimate performance